

# YRC-6V Operation Guide



# catalogue

Preface .....	I
Chapter 1 Basic understanding of equipment .....	1
1.1 Device Overview .....	1
1.2 Back panel of the device .....	2
1.3 Host operation page .....	2
1.4 Work chamber door .....	3
1.5 Work cabin .....	4
1.6 Coolant passage .....	4
1.7 Technical parameter .....	5
Chapter 2 Equipment transportation and installation .....	6
2.1 Handling, packing and storage .....	6
2.1.1 Safety Guidelines for Transportation .....	6
2.1.2 Packaging .....	6
2.1.3 Markings on Outer Packaging .....	7
2.2 Accessories .....	7
2.3 Installation conditions .....	8
2.4 Equipment Installation .....	9
2.5 Removal and disposal of work chamber fillers .....	9
2.6 Pneumatic unit mounting device .....	10
2.6.1 Introduction to pressure regulating filter .....	10
2.7 Installation of Water Circulation Filtration System .....	11
2.7.1 Requirements for the Filter Tank .....	11
2.7.2 Installation of the Circulating Filter Tank .....	11
Chapter 3 Device operation .....	13
3.1 Pre-Run preparation .....	13
3.2 Power on the device .....	13
3.3 Device testing .....	13
3.4 Overview of the cutting process .....	14

3.5 Tool Insertion and Replacement .....	15
3.6 Car needle information .....	17
3.7 Install and disassemble the tray .....	17
3.7.1 Load tray .....	18
3.7.2 Remove tray .....	18
3.8 Program interrupt and stop .....	19
3.8.1 Interrupt handling method .....	19
3.8.2 Methods for handling equipment failures .....	19
3.8.3 Methods for dealing with damaged cutting tools .....	19
Chapter 4 Operating System Page .....	21
4.1 Main interface introduction .....	21
4.1.1 Main Page Function Description .....	21
4.2 Settings Interface Description .....	24
Chapter 5 Equipment maintenance and cleaning .....	28
5.1 Safety Notice! .....	28
5.2 Accessories replacement warning! .....	28
5.3 Regular cleaning .....	29
5.3.1 Cleaning requirements for equipment and parts .....	29
5.3.2 Clean the spindle chuck .....	29
5.3.3 Check the hose, cable, and connections. ....	30
5.3.4 Check the pressure regulating filter. ....	30
5.4 Guide maintenance .....	31
5.5 Cleaning of the circulating water tank .....	31
5.6 Maintenance Schedule .....	32
5.7 Device calibration .....	33
Disclaimer .....	34

## Preface

Dear User:


Welcome to your YRC-6X equipment. To ensure safe, efficient, and stable operation, this manual systematically outlines key operational procedures and safety protocols as core guidelines. Before first use, please read the manual thoroughly and strictly follow all operational procedures, parameter standards, and maintenance requirements. Keep the manual in a dry, easily accessible location (such as a dedicated file box) for all operators to consult. For product improvement suggestions or operational questions, please contact your designated dealer at any time.

Thank you for your trust and support in our product. We hope you enjoy using it!

## Chapter 1 Basic understanding of equipment

### 1.1 Device Overview


The YRC-6X 5-axis cutting machine is designed for the dental technology field to facilitate digital processing, capable of handling various materials.



YRC-6X Schematic Diagram

1.Cutting machine 2.Cooling fan 3.Work compartment door 4.Work compartment viewing window 5.Digital pressure gauge/USB port 6.Main System 7.Power on/off button 8.Emergency stop button 9.Machining alert display bar 10.CMOS battery


## 1.2 Back panel of the device



Rear Connection Panel

- 1. 220V AC power supply interface
- 2. water pump power output port
- 3. Cutting fluid outlet
- 4. Network port
- 5. Air intake vent
- 6. Cutting fluid inlet
- 7. Dual-cup air pressure filter

## 1.3 Host operation page



Control panel diagram


- 1. System display
- 2. Emergency stop button
- 3. Power on/off button

## 1.4 Work chamber door

The work chamber door must be closed during machine operation to prevent personnel injury.

**[Note]:** Be careful to avoid being pinched when opening or closing the hatch.


- ◆ When opening the hatch, hold the handle and pull it outward.
- ◆ When closing the hatch, place your hand on the lower edge of the hatch and push it up.



Schematic diagram of the YRC-6X 5W opening the hatch

## 1.5 Work cabin

A compartment used for machining raw materials.



YRC-6X Work Chamber

1. Tool setting device   2. Tool magazine   3. Work piece fixture   4. Fourth rotary axis  
5. Fifth rotary axis   6. Spindle

## 1.6 Coolant passage

This equipment's cooling system consists of two components:

1. Gas cooling system: The gas blown out from the spindle and the jet pipe forms a gas cooling loop;
2. External cutting fluid cooling system: an external cutting cooling module independent of gas cooling.

During the normal operation of the equipment, the water tank will continuously inject the cutting fluid into the working chamber. During the operation, the cutting fluid can carry away the heat generated by the spindle tool and the blank processing in time, and then return to the water tank through the coolant circulation system to complete the cooling cycle.

Stable operation of the cooling system can effectively avoid the damage or excessive wear of sensitive parts of the equipment due to high temperature, and can reduce the rate of tool wear, prolong the service life of the tool, and ensure the machining accuracy and

efficiency.

**[Note]:** The cooling system cannot replace regular machine cleaning. If the machine is not cleaned regularly, its lifespan will be significantly reduced.

### 1.7 Technical parameter

Specifications	Parameters
Number of axes	5-axis Linkage
Cutting Method	Wet milling
Cutting Material	PMMA polymer resin, glass ceramics, titanium columns, etc.
Processable Types	Veneers, inlays, onlays, full crowns, implant superstructures, etc.
Travel Range	X/Y/Z: 200-100-100 A: 360° B: +30° ~-90°
Spindle speed	0 - 60,000 rpm / 800 W
Drive	Fully Servo Motor
Cutting Tools	Quantity: 10 Shank Diameter: 4mm
Dimensions	650*530*775 mm
Weight	Total cutting machine weight: 160 kg
Required Air Pressure	4.5–7.5 bar
Compressed air flow rate	Approximately 50 litres per minute
Rated Power	2KW
Power supply	220-230V AC, 50/60Hz

## Chapter 2 Equipment transportation and installation

### 2.1 Handling, packing and storage

△ Warning: To ensure proper equipment operation, transport packaging must be handled by qualified operators or maintenance personnel. Please review the following handling precautions carefully.

#### 2.1.1 Safety Guidelines for Transportation

- ◆ Before moving the equipment, the center of gravity must be clearly identified. During transportation, any shift in the center of gravity must be strictly avoided to prevent tilting or falling.

- ◆ Before moving, check the weight and orientation labels on the equipment's outer packaging to ensure it remains balanced during transportation.

- ◆ When using lifting machinery, the force part of the machinery should always be around the center of gravity of the equipment, and the equipment should be shaken as little as possible.

- ◆ When lifting or lowering equipment, keep an eye on its tilt. If possible, lower the packaging height to improve safety.

- ◆ During handling, only the designated force-bearing areas of the equipment may be used; applying force to non-designated areas is strictly prohibited.

- ◆ Equipment outsourcing materials must be removed after installation is completed. They cannot be disassembled before installation.

#### 2.1.2 Packaging

This equipment's transport packaging is specially designed for the intended transportation method and conditions, featuring specialized protective structures to minimize physical damage and other risks during transit. The packaging must be removed before installation. When removing the packaging, ensure its integrity is maintained and keep a spare copy for reuse when the equipment needs to be returned to the factory.


2.1.3 Markings on Outer Packaging.



The equipment is a high-precision instrument with many vulnerable parts inside, so handle it gently during transportation.



The interior contains numerous electronic components and water-resistant mechanical parts, so avoid moisture exposure.



When temporarily placing or storing equipment, place it in the direction of the arrow.



Do not let the packing box be tilted or rolled during transportation and handling.

2.2 Accessories

First, check the delivery list to ensure completeness. Open the machine packaging and count the following items:


Serial Number	Item Name	Specification	Unit	Quantity
1	YRC-6X	650*530*775 mm	Set	1
2	Power cord	US Standard/European Standard	Piece	1
3	Screwdriver	Phillips, flat	Pieces	2
4	Tee fittings	T-Tee/Y-Tee	Piece	2
5	Hex Key	1-10	Set	1
6	Air tube	φ 8-5m	Piece	1
7	Drainage pipe	φ20-1.5m	Piece	1
8	Water tank	290×310×505 mm	Piece	1
9	Water Pump	220V	Piece	1
10	Filter cotton		Sheet	3
11	Cleaning brush		pieces	2
12	Cleaning Scoop		Piece	1
13	Spindle wrench		Piece	1
Serial Number	Item Name	Specification	Unit	Quantity
14	Lifting Handle		Piece	4
15	Hardened Cup Head	6*M5	pieces	6

## YRC-6X

	Screw			
16	Calibration block		Piece	10
17	Inlet pipe	10m	Pieces	1
18	USB drive		Piece	1
19	Pipe clamps		Piece	1
20	Teflon tape		Roll	1
21	Fuse rod		Piece	2
22	Spindle probe accessories	Probe, probe cable	Set	1
23	Wireless WiFi Kit	Wireless connectors, network cables	Set	1
24	Cutting fluid		bottle	2

### 2.3 Installation conditions


- ◆ The installation site must have sufficient load-bearing capacity (approximately 160KG) and a solid, flat surface.
- ◆ The indoor temperature should be maintained between 18°C and 25°C (the ideal range), with a maximum of 32°C.
- ◆ Set the installation location in a dust-free environment.
- ◆ The relative humidity of the air must be below 80%
- ◆ The power supply must provide 220-240 V AC at 50/60 Hz.
- ◆ Compression requires compressed air that meets the equipment requirements, with a pressure range of 4.5-7.5bar
- ◆ Ensure sufficient operational space around the equipment installation, with specific dimensions shown in the attached diagram.



**【Note】** : Connect the equipment power cable to an independent circuit protected by a fuse, or ensure no other equipment shares this power circuit to effectively prevent voltage fluctuations. Severe voltage fluctuations may interfere with the normal operation of the equipment control system, potentially causing system malfunctions.

## 2.4 Equipment Installation

The device connection is shown in the figure:



Equipment Connection Diagram

## 2.5 Removal and disposal of work chamber fillers

Before the equipment is first started, the transport filler in the working chamber must be removed. This filler protects the spindle and machine tool structure during transportation,

preventing damage from vibrations or impacts. The specific operational requirements are as follows:

1. Open the equipment work chamber and remove all internal transport fillers completely;
2. Clean the interior of the work cabin to ensure no debris or filler remains;
3. Store the removed filler properly for reuse when the equipment needs to be transported (e.g., returned to the factory or relocated).

## 2.6 Pneumatic unit mounting device

1、 Installation and maintenance guidelines: During equipment installation and maintenance, ensure no compressed air flows through the pressure regulator filter.

2、 Pneumatic hose installation inspection: After installation but before inflation, ensure the hose is securely inserted into the connector and is undamaged.

3、 Compressed air connection specification: The machine must be connected to the compressed air supply source exclusively through the pressure regulator and filter provided with the equipment.

**[Note]:** The compressed air supplied to the input device must be oil-free and dry. Contaminated compressed air (e.g., moisture or oil) may damage the spindle and electrical components.

### 2.6.1 Introduction to pressure regulating filter

Compressed air is connected to the machine through a pressure regulator and filter, which can be used to regulate the pressure input to the machine and separate moisture from the gas.



## Pressure regulating filter diagram

### 2.7 Installation of Water Circulation Filtration System

#### 2.7.1 Requirements for the Filter Tank

Only filtration tanks with the following characteristics may be used:

- ◆ Specifically designed for the dental sector, meeting the water requirements and operational scenarios of dental equipment.
- ◆ Effectively intercepts minute particles generated during processing to ensure clean circulating water.
- ◆ Compatible with machine tool operating environments, presenting no issues regarding temperature, humidity, or spatial layout.
- ◆ Equipped with comprehensive safety installations to prevent injury to operators during operation and maintenance.
- ◆ The maximum flow rate must reach 4500ml/h to meet the equipment's water circulation requirements, ensuring cooling and flushing functions.

#### 2.7.2 Installation of the Circulating Filter Tank

Prior to installation, please carefully review the equipment installation manual. The specific steps are as follows:

1. **Compatibility check:** Verify compatibility between the recirculating filter tank and the corrugated hose. Should incompatibility arise, replace with a suitable hose. Under no circumstances should incompatible tubing be forcibly used.

2. **Corrugated Hose Connection:**

- Securely insert one end into the tank inlet, ensuring full insertion depth and a tight seal to prevent leaks;
- Securely connect the other end to the machine's outlet port and verify the reliability of the connection.

**3. Electrical and Water Connections:**

- Insert the pump's power plug into the machine's designated power supply port, ensuring correct wiring to prevent short circuits;
- Properly connect the inlet hose to the machine's inlet port, ensuring the water circuit is unobstructed, well-sealed, and leak-proof.

## Chapter 3 Device operation

### 3.1 Pre-Run preparation

Before starting the device, complete the following checks to ensure it meets the operating conditions:

1. Ensure the equipment is placed on a flat and stable surface to prevent vibration or shaking.
2. Check that all parts are properly installed and all connections are functioning normally;
3. Ensure all parts and accessories are securely fastened without any looseness or displacement.
4. Confirm all control systems are installed and can operate normally after power-on testing.

### 3.2 Power on the device

1. All equipment has been fully installed with sufficient compressed air supply, and the work chamber door remains closed. Note that the door must stay closed during startup and operation.

2. Press the power button on the host control panel to turn on the device.

3. The device automatically resets to its original position. After the control system is fully activated, the device will enter the automatic reset program. Subsequent operations can only be performed after the reset action is completed and the display reminder window is closed. Do not operate the device before resetting to the origin.

### 3.3 Device testing

After the first installation or reinstallation after transportation, test the basic performance of the equipment as follows:

1. Insert the needle into the device;

2. Do not load the material tray. Load any program and run the device.
3. Monitor the equipment's operational status and verify the proper functioning of functions including gear shifting, air blowing, and shaft rotation.
4. Confirm the device is functioning properly. If the device fails to operate, contact the supplier immediately.

### 3.4 Overview of the cutting process

#### **[Important Notes]:**

- ◆ Before processing, make sure to read the operation manual and safety guidelines, and familiarize yourself with the operational standards and safety requirements.
- ◆ Before operation, thoroughly inspect the needle and material tray for damage. Any damage may cause part defects and equipment failure during processing.
- ◆ The NC program for the equipment, generated by CAM software like HyperDENT through layout and calculation, contains all machining parameters and instructions. It can be transmitted to the equipment's operating system via USB interface or network communication.


YRC-6X processing steps:

1. Open the layout software, select the required material block size and type based on processing needs, then complete the layout.
2. Insert the adapter needle into the designated position of the device as specified by the installation requirements.
3. Position the work piece tray on the equipment's tray mounting station, ensuring it is securely clamped without any looseness.
4. Click the "Load" button on the device interface, then select the required machining program from the program list.
5. After confirming the correct procedure selection, click the 'Start' button to initiate the device's processing operation.

### 3.5 Tool Insertion and Replacement

- Use the correct adapter needle; mismatched model specifications may damage the spindle chuck or tool magazine.
- The handle of the lathe needle knife should be chamfered with sufficient dimensions, otherwise the chuck will be damaged.
- Do not use a needle with a blade diameter exceeding the handle diameter ( $\varnothing 4\text{mm}$ ).

You can insert the 6 supplied burs into the tool magazine as shown in the figure. The device can automatically change burs during machining.




Tool Magazine Diagram

You can install the needle in two ways:

- Insert the needle into the tool magazine manually.
  - ① Set the spindle to the safe position, then proceed to the second page of the operating system. Hold the center of the spindle's needle with your hand and click 'Release Tool' to remove it.
  - ② Insert the new needle into the spindle. Ensure the needle's fixing copper ring (as shown) is tightly secured against the spindle chuck. Then press the 'Release Clamping Tool'

button to secure the needle.



wheel diagram

③ Press the "Align" button to measure the length of the new blade and automatically record it in the system.

**[Note]:** After each tool release, always check the blade length regardless of needle replacement. Failure to do so may damage work pieces or even cause blade breakage.

● Through the spindle.

① Move all axes to default positions to ensure the fixture is free of material blocks and the spindle chuck is clear of lathes. If lathes are detected in the chuck, navigate to the second page of the operating system and click 'T0' to automatically return the lathes to the tool holder.

② Remove the old needle one by one in the tool holder.

③ Insert the new pins into the corresponding tool holders in sequence, ensuring the positioning copper rings are fully embedded to prevent improper installation.

④ Check the needle placement sequence and position of the new needle to ensure proper functioning of the automatic needle replacement feature.

**[Caution]:**


- Avoid direct impact when installing the needle to prevent damage that may affect machining accuracy or cause equipment failure.

- If the lathe needle runs beyond the preset time or if the workpiece damage is suspected to be caused by the lathe needle, it should be replaced promptly.

- The tool library is prioritized for tool change, except when the spindle tool is damaged and length measurement is impossible.


- The needle must be placed into the designated holder according to the preset specifications. Misplacement or mixing is strictly prohibited.

- Only the personnel who are familiar with the equipment and software can replace the needle after training.
- The operating system displays the default tool number. If all tool pins are properly returned to the tool library, the tool number will show as '0', as shown in the figure.



Tool Number Display

- The system checks the length of the needle before and after each extraction or reinsertion. The length deviation must not exceed the preset range. If the needle is not detected or the deviation exceeds the range, the system will display the following message.



tool break diagram


- If the tool error message appears during processing, check the lathe needle or replace it and restart the program.

### 3.6 Car needle information

Tool Number	Specifications	Tool Number	Specification
T01	Emax2.5	T05	Premill-3.0
T02	Emax1.0	T06	Premill-2.0
T03	Emax0.6	T07	Premill-1.0

### 3.7 Install and disassemble the tray

The YRC-6X fixture is an open-type design, with the raw material mounting fixture (as shown in the figure) installed.




Fixture Diagram

### 3.7.1 Load tray

Secure the glass-ceramic/titanium column with a fixture, as shown in the figure.

- (1) Open the work chamber door and clean the fixture groove thoroughly;
- (2) Use a screwdriver to loosen the screws on the fixture;

Place the raw material into the fixture and tighten the fixing screws with a screwdriver, as shown in the figure.



Material Tray Securing Diagram

**[Note]:** Ensure all screws are securely tightened. Any movement or vibration of the material tray during cutting may cause equipment damage.

### 3.7.2 Remove tray

To remove the part, simply loosen the fixing screw and pull it out.

### 3.8 Program interrupt and stop

**[Note]:** When the program is interrupted or stopped, the operating system page will display a corresponding alert window to indicate the exception.

If the device's air pressure is insufficient, the program will pause automatically. When the pressure returns to the normal range, the program will restart and continue.

You must manually cancel the current program when the following conditions occur:

- When the device fails;
- When the tool is damaged;
- During a sudden power outage;
- When the cutting fluid supply is abnormal.

If the program is canceled, restart the program in the device system to resume operation.

#### 3.8.1 Interrupt handling method

If an interrupt occurs during program execution, the operating system page displays the corresponding information.

The device shows insufficient air pressure. Check the following:

- Check whether the pressure values on the pressure-adjusted filter element and the barometer are within the correct range.
  - whether there is air leakage in the trachea;
  - Check if the air compressor is working properly.

#### 3.8.2 Methods for handling equipment failures

When a device failure is triggered by an emergency, the control unit issues corresponding commands, and the operating system interface displays the fault-related error message and error code for the operator to identify.

If the alarm cannot be resolved through standard troubleshooting, immediately document all alarm details (including error codes and fault symptoms) and contact the manufacturer's after-sales service for professional assistance.

#### 3.8.3 Methods for dealing with damaged cutting tools

When the tool breaks during processing, the equipment cannot detect it immediately, and the spindle will continue rotating and cutting until the next lathe needle is replaced. Only

during the lathe needle length measurement, if the length is abnormal, the program will report an error, and the error message will be displayed on the operating system interface.

Common causes of breakage:

- The wheel itself is damaged or excessively worn;
- The material selected for layout does not match the material actually processed
- The lathe needle is incorrectly positioned or manually inserted into the spindle at an

improper time, making it unsuitable for the current machining step. Therefore, the lathe needle must be replaced. The steps are as follows:

① Open the working hatch of the equipment;

② Remove the broken needle from the work chamber;

③ If the lathe needle is retrieved from the tool magazine by the spindle, first verify the correct placement of the needle in the tool magazine. After confirmation, insert the new compatible lathe needle into the designated position.

④ If the needle is manually loaded onto the spindle, verify that the damaged needle matches the designated needle displayed on the operating system interface, then prepare and load the new correct needle.

⑤ Close the work compartment door and restart the programme.

## Chapter 4 Operating System Page

### 4.1 Main interface introduction

The main interface serves as the core operational and monitoring hub of the equipment, integrating full-process machining functions with visualised status modules. This interface facilitates core operations including machining data output, real-time operational feedback, and fault alert notifications. Upon equipment startup, it will automatically transition to the following main interface.



Main Interface Diagram

#### 4.1.1 Main Page Function Description



※Loader: Click the "Loader" button on the screen to select a machining programme. All

programmes within the system can be opened for use, with the default format being NC documents.

※ Import program: When copying programmes via USB, click the "Import programme" button and select the required programme from the left-hand list in the pop-up window.

※ System Operation: Clicking this button automatically navigates the system to the second auxiliary page.



※ Break Point Processing: Resumes machining after the program is interrupted due to an abnormal condition.

※ Boot to Zero: Press this button to initiate the homing sequence for all axes of the device.

※ Start Up: Runs the currently loaded program.

※ Pause: Pauses the device during machining.

※ Reset: Resets the current device status (machining or alarm mode), typically used to clear alarm states.

● Axis Coordinate Information Display


	Machine coordinates		absolute coordinates
X	22.027	X	-149.953
Y	37.689	Y	44.959
Z	4.850	Z	64.999
A	59.998	A	59.998
B	-29.996	B	-29.999

● Status

Display


Description

Displays the current feed rate, spindle speed, machining progress, file processing time, current tool number, and current line number.



- Process Display


Feed rate progress bar control. This progress bar enables adjustment of machining speed (increase or decrease).



- Machining status display

Status	Colour
Processing	Green
Alarm	Red
Processing complete	Green & Red Alternating
Idle Status	Blue

## 4.2 Settings Interface Description



Settings Interface Diagram

- Clamping Position

When clamping a work piece is required, click "Clamping position" and the machine's axes will move to a position facilitating work piece clamping.

- Ti Clamping Position

When installing a titanium column, click "Ti Clamping position" and the cutting machine's axes will move to a position facilitating titanium column installation.

- Tool setting

Upon clicking the "Tool setting" button, the tool length of the turning tool currently mounted on the spindle will be measured and recorded in the system.

- Tool change

Clicking the "Tool change" button initiates manual tool replacement. Following tool change, tool setting is automatically completed.

- Knife reset

Pressing the "Knife reset" button automatically resets the system's currently active tool number to tool number 0.

- Software installation

This button is primarily used for system software upgrades.

- Delete program

When the system requires deletion of excess stored programme files, click the "Delete programme" button and select the files to be deleted in the pop-up window.

- Network settings


When connecting the device to a network, access the "Network settings" interface to manually configure the correct IP address and gateway, enabling NC file transmission over the network.

- Spindle start

Manually activate spindle rotation.

- Cutting fluid

Manual switch for cutting fluid; an alarm will sound if not connected or if water flow is insufficient.



- Working lamp

Provides illumination for the machine's working area.

- Loose clamp knife

Should the lathe needle malfunction or become damaged requiring replacement, click "Loose clamp knife" to open the spindle chuck and remove the needle. After correctly inserting the new needle, click again to close the spindle chuck.

**[Note]:** Each time the tool is removed and reinserted or replaced, it is essential to click "Tool setting" to perform a current tool length detection.

- Hand wheel

Press this button to manually adjust the position of each axis.

- Maintain

Clicking "Maintain" displays a pop-up window showing the device's system serial number and usage expiry date.

- <<

Return to the previous screen.

- >>

Upon clicking the ">>" button in the system interface, an auxiliary page requiring password verification will appear. Access this page via password authentication to store and retrieve coordinates, modify external offset coordinate parameters, and simultaneously view real-time coordinate information and the current tool position.

The screenshot displays the YRC-6X system interface. At the top, it shows the date and time (2025/12/8 17:21:29), the program name (11.NC.N0.L1), and the status (Ready). Navigation buttons include HOME, Home Page, and Alarm. The main display area is divided into several sections:

- Tool Information:** Shows tool IDs (P2003, P2022), tool numbers (2, 320), tool offsets (P3448, P3855), and tool lengths (55000, 1000).
- Coordinate Management:** Includes buttons for "Tool MAG setting", "home set", "Tool management", and "position correction".
- Coordinate Display:** A table showing Machine coordinates and External Shift for X, Y, Z, A, and B axes.
- Execute Write:** A section with a dropdown menu (currently showing 0.000) and an "execute write" button.
- Coordinate Storage & Recall:** Buttons for "coordinate storage" and "coordinate reading".
- Text Input:** A section labeled "txt" with input fields for X, Y, Z, A, and B, all currently showing 0.000.
- Password Field:** A "password" field with a "\*" character.

- Coordinate Storage & Recall

Store the current device's set coordinates, or retrieve previously saved coordinates via this function when the device experiences offset.

- Execute write

Select the axis requiring modification, input the coordinate values, and click to execute the write operation to overwrite the original coordinates.

- Coordinate Display Area

Displays the current mechanical coordinates and the set external offset coordinates.

- TOOL MAG setting


Click to open the tool magazine tool holder coordinate setting interface.

- Home set

Switch between absolute and incremental values; usable when the origin switch is damaged.

- Tool management

Display the current tool's usage life and maximum life.



- Position correction

Calibrate each axis position using the automatic probe to determine if any changes have occurred.

## Chapter 5 Equipment maintenance and cleaning

### 5.1 Safety Notice!

To ensure stable processing accuracy and extend the service life of the equipment, we recommend regular maintenance and care. Before maintenance, make sure all axes are adjusted to a safe position, and turn off the power and unplug the power cord to ensure safe operation.

△ Warning: After powering off the device, residual electricity may remain in internal components. To avoid electric shock, wait several minutes after power-off until all components are fully discharged before performing maintenance.

△ Note: When cleaning the equipment, use a damp cloth. For better cleaning results, choose a suitable cleaner. Do not use abrasive cleaners to avoid scratching the equipment surface, or cleaners containing corrosive components for rubber parts to prevent aging and damage to seals, hoses, and other components.

All maintenance and related operations must be performed by professionally trained and certified personnel. Unauthorized operation is strictly prohibited. Before inspecting the equipment's pneumatic system, the main switch must be turned off, and the system's internal pressure and the entire air duct must be depressurized to atmospheric levels to prevent high-pressure gas release and potential safety hazards.

### 5.2 Accessories replacement warning!

Using non-manufactured or unsuitable parts may pose risks to operators and could result in equipment damage or complete failure. Therefore, only original manufacturer parts or manufacturer-authorized parts are permitted.

For questions, contact the manufacturer's customer service.

## 5.3 Regular cleaning

### 5.3.1 Cleaning requirements for equipment and parts

1. Daily cleaning can extend the service life of individual components and prevent malfunctions caused by debris.
2. Regular cleaning can extend the service life of the equipment.
3. For cleaning plastic components, use a suitable liquid cleaner to ensure the process does not damage the plastic surface or material properties.
4. To prevent dust or impurities from entering the core components and causing malfunctions or damage, do not use a gas gun to clean the equipment's interior.
5. When installing materials, ensure the fixture and screws are clean to achieve optimal clamping performance.
6. The tool magazine and tool setter must be free of chips and debris to ensure accurate length measurement and tool replacement. If any damage is found, contact the manufacturer immediately for replacement.

### 5.3.2 Clean the spindle chuck

Avoid spraying oily mist or compressed air with oil-water mixture directly onto the spindle head, as this may allow contaminants to infiltrate the spindle bearing, potentially impairing its rotational performance or causing bearing damage.

The spindle chuck and the inserted lathe needle must be kept clean, if impurities enter the spindle, it will increase the resistance of the spindle rotation, and affect the rotation concentricity.

The spindle chuck should be cleaned weekly under normal conditions. If the lathe needle is damaged due to impact, the spindle chuck must also be cleaned simultaneously.

Note: Always use the dedicated tool to handle the spindle chuck, as shown in the figure.



Diagram of the hexagonal wrench for the spindle chuck

△ Warning: Do not close the spindle chuck when it is not loaded. Rotating the spindle

without a chuck may cause damage. Ensure the chuck always has a lathe needle.

Clean the spindle chuck:

- a. Reset the device to a safe position;
- b. Confirm that the spindle has stopped rotating;
- c. Use a specialized tool to remove the spindle chuck;
- d. Clean the hole for the chuck to be placed on the spindle;
- e. Clean the chuck with a small brush to ensure there are no residual impurities on its surface.

d. Reinstall the cleaned chuck onto the spindle, ensuring it is securely tightened.

#### 5.3.3 Check the hose, cable, and connections.

i. First, power off the equipment and cut off the compressed air supply before conducting the inspection.

ii. Check the hose and cable connections to ensure they are properly secured; also verify that all connections on the connection plate are tight and not loose.

iii. If the hose or cable is damaged, do not restart the device. Immediately replace the damaged component with a spare part.

iv. If cables or hoses are loose, reinsert them into the corresponding connection points. If the connection is damaged, immediately stop using the equipment and contact after-sales service for assistance.

#### 5.3.4 Check the pressure regulating filter.

Regular inspection: The air source dryer should undergo a comprehensive monthly inspection. As it typically contains integrated filter components, any impurities affecting its performance during inspection must be removed to ensure proper functioning of the filters.

Disassembly and cleaning: The dryer must be disassembled from the equipment annually for thorough cleaning of internal components to ensure efficient operation.

Cleaning agent selection: Neutral cleaning agents should be used during cleaning. The use of corrosive substances such as chemicals, organic solvents, thread locking agents, synthetic oils, cutting fluids, salts, or alkalis is strictly prohibited. These corrosive substances may cause rusting of dryer components or damage to rubber and resin parts, thereby affecting


their normal operation.

[Note]: If the air source dryer becomes contaminated, it may cause equipment damage. Regular inspection and maintenance should be performed as required.

## 5.4 Guide maintenance

Regular maintenance of the screw and guide rail helps maintain machining accuracy and prolong equipment lifespan. The procedure is as follows:

- ① Turn off the device power.
- ② Remove the screws connecting the device's side cover and rear cover, then detach the rear cover as shown in the diagram.
- ③ Use a vacuum cleaner to remove debris from inside the equipment, then wipe the dirt off the screw rod and guide rail with clean paper towels.
- ④ Apply grease evenly to the cleaned screw rod and guide rail surfaces.
- ⑤ Reinstall the removed cover plate. If you encounter any issues during maintenance, contact customer service immediately.




Equipment cover plate removal diagram

## 5.5 Cleaning of the circulating water tank

Regular cleaning of the circulating water tank helps extend the service life of the pump

and related components, while improving the surface finish of processed parts. The procedure is as follows:

- (1) Turn off the device power.
- (2) Remove the inlet/outlet pipes; if possible, take out the water pump for cleaning as well.
- (3) Remove the filter cotton from the water tank and clean it thoroughly.
- (4) Clean the water level gauge and sewage pipe.
- (5) Rinse the tank several times with clean water until no visible dirt remains.
- (6) The filter cotton, water pump, water pipe and other parts were installed back to the original position in turn.
- (7) Add water and cutting fluid to the water pipe in the proportion of 1:20.



Schematic diagram of the circulating water tank

## 5.6 Maintenance Schedule

Maintenance Project	period
Clean the work chamber, tool setter, tool magazine, and needle holder.	every day
cleaning spindle chuck	weekly

YRC-6X

pressure regulating filter	weekly
Clean the screw rod and guide rail	semiannually
accessory equipment	weekly
machine tool calibration	if necessary

### 5.7 Device calibration

This equipment has undergone professional calibration before leaving the factory. If the processed products meet quality standards (with no defects), no additional calibration is required.

The calibration process requires a certain amount of time, and improper operation may cause equipment failure or even irreversible damage. It must be performed with caution.

If the processing result is not as expected, the working conditions should be adjusted first, including checking whether the work piece is fixed firmly, the wear and installation status of the turning needle, and whether the processing material meets the equipment compatibility requirements.

Before equipment calibration is required, you must contact the supplier for professional guidance. During calibration, strictly control the accuracy of reading and entering measurement data. If any operational issues arise, immediately stop the calibration process and continue only after confirming with the supplier.

## Disclaimer

To ensure proper equipment operation and protect both parties' legitimate rights, as the manufacturer, we hereby inform you: Please carefully review the following disclaimer before reading and using this equipment manual. By starting or using this equipment, you acknowledge and accept all terms of this disclaimer and will comply with its provisions.

1. The operational guidelines and safety precautions outlined in this equipment manual are designed to ensure safe and standardized operation. Please read and fully understand all content, and strictly follow the specified procedures throughout your use. The manufacturer shall not be held liable for any accidents, personal injuries, or property damage resulting from non-compliance with these guidelines or procedures.

2. Usage Restrictions: The information and operational guidelines provided in this equipment manual are strictly limited to the device's intended design purpose and specified usage scenarios. Any use of the equipment in unexpected, improper, or hazardous ways is strictly prohibited. The manufacturer shall not be held liable for any losses, personal injuries, or property damage resulting from improper use of the equipment.

3. Disclaimer: All information and content in this equipment manual are provided based on existing knowledge and technology. The manufacturer has made every effort to ensure their accuracy and completeness. However, the manufacturer shall not be liable for any loss, damage, or inconvenience caused by errors, omissions, or inaccuracies in the manual.

4. Legal Compliance: Users must comply with applicable laws, regulations, and rules to ensure their equipment usage meets regulatory requirements. The manufacturer shall not be liable for any consequences arising from users' non-compliant equipment use.

5. Warranty Limitations: The warranty coverage and duration are subject to the specified warranty terms. The manufacturer shall not be liable for any issues or damages beyond the warranty scope or period. Please read and understand this disclaimer in detail before using the equipment.

If you have questions about safe operation of the device or need additional information,

please contact the manufacturer or authorized representative. By using this device, you acknowledge and agree to the terms of this disclaimer, and accept the potential risks and liabilities associated with its use.